

From: Outbound

Con: Repair instruction re-glue metal placeholder on glass plate

Please follow the steps below to re-glue the metal placeholder with the black MS Polymeer glue

- Dismount the black alu placeholder from the gas strut (One stainless steel screw)
- Make a template to re-position the black alu placeholder
- Remove the old glue from the black alu placeholder and glass plate. Please do this carefully with a flat knife
- Lightly sand the surface of the black aluminium plate with sandpaper
- Remove all grease, dust from both surfaces with a degreaser
- Apply the black MS Polymeer glue on the surface of the black alu placeholder
- Put the black alu placeholder with the MS Polymeer on the glass plate and put some pressure on the alu placeholder to make sure that the glue is qually spread
- Let it dry for minimum 48 hours
- After drying for 24 hours, mount the gas spring again. Open the window before doing this.

If you follow the above step it should work.

In case of questions don't hesitate to call us;

Outbound BV

info@outbound.eu

+31 (0) 492 76 0034